

# Installation instructions

## ADHERO Floor Drain

### Installation of the ADHERO Floor Drain



#### 1. Preparation

Drill a hole with a diameter of at least 70 mm (2 3/4") through both the SOLITEX ADHERO and the structure underneath it.

Clean subsurfaces before taping. Adhesion is not possible on frozen surfaces. There must be no water-repellent substances (e.g. grease or silicone) on materials to be stuck. Subsurfaces must be sufficiently dry and stable. If necessary, remove any moisture with a wet-and-dry vacuum cleaner.

#### 3. Connect drainage pipe

Connect the plastic pipe or temporary downpipe to the outlet of the floor drain and secure it to prevent it slipping off. Ensure the drainage water is piped out of the building reliably.



#### 2. Installation

Insert the floor drain into the drillhole (if necessary, secure with countersunk screws) and tape it to the SOLITEX ADHERO with no folds or creases using TESCON VANA.

This adhesive tape should cover approx. 30 to 50 mm (12" to 20") of both the membrane and the ADHERO Floor Drain. Any water that is collected is to be drained from the building.

The information provided here is based on practical experience and the current state of knowledge. We reserve the right to make changes to the recommended designs and processing or to make alterations due to technical developments and associated improvements in the quality of our products. We would be happy to inform you of the current technical state of the art at the time you use our products.

Further information about installation and design details is available in the pro clima planning documentation. If you have any questions, please contact [pro clima Technical Support](<https://proclima.com/service/technical-support>).

**MOLL**  
bauökologische Produkte GmbH  
Rheinthalstraße 35 - 43  
D-68723 Schwetzingen  
Fon: +49 (0) 62 02 - 27 82.0  
eMail: [info@proclima.de](mailto:info@proclima.de)